

PRODUCT DATA SHEET

Casco[®] Remover

CONCENTRATED WALLPAPER REMOVER.

DESCRIPTION

A concentrated wallpaper remover for removing paper-, vinyl- and nonwoven wallpaper on most surfaces. 1 liter Remover gives 6 liter ready product.

USES

For removal of:

- Nonwoven wall paper
- Paper wall paper
- Vinyl wall paper (outer layer needs to be removed)

CHARACTERISTICS / ADVANTAGES

- Concentrated, gives 6L
- No splashing
- Easy to apply with roller, brush, or sponge
- Water based

PRODUCT INFORMATION

Composition	Polysaccharide solution and fatty acid ester wetting agents.
Packaging	1L
Shelf life	12 months from production date (s. packaging) in an unopened bucket. Opened buckets should be closed immediately and used up as soon as possible.
Storage conditions	Store in dry and cool conditions.
Appearance and colour	Transparent tixotropic liquid
Density	1000 kg/m ³

APPLICATION INFORMATION

Consumption	One mixed bottle is enough for approx 30 - 50 m ² of wall.
Substrate temperature	Between +5°C to +25°C

BASIS OF PRODUCT DATA

All technical data stated in this Product Data Sheet are based on laboratory tests. Actual measured data may vary due to circumstances beyond our control.

ECOLOGY, HEALTH AND SAFETY

For information and advice on the safe handling, storage and disposal of chemical products, users shall refer to the most recent Safety Data Sheet (SDS) containing physical, ecological, toxicological and other safety-related data.

APPLICATION INSTRUCTIONS

MIXING

Mix 1 bottle (1L) of Remover with approx. 5 liters of tepid water. Start with a small amount of water for the best mix-ability, and then add the rest. Mix well.

APPLICATION METHOD / TOOLS

Use sponge, brush or roller.

APPLICATION

- Apply plenty of the mixture to the wall, with a sponge, brush, or roller. Use rubber gloves.
- Let the mixture work for at least 15 minutes, however, the mixture must not dry. If the mixture dries, add water with a spray bottle or likewise.
- Then scrape the wallpaper with a steel trowel. If the wallpaper does not come off easily, repeat the process.
- When removing wallpaper with a non-absorbent outer layer, the surface must first be perforated with a pigg-/spike roller or possibly a steel brush.
- For vinyl wallpaper, remove the outer layer first, then apply the Casco® Remover.

CLEANING OF EQUIPMENT

On contact with the skin, wash off with soap and water. Clean tools with water.

Sika Sverige AB

Domnarvsgatan 15
Box 8061
SE- 163 08 Spånga Sweden
TEL: +46 8 621 89 00
info@se.sika.com
www.casco.eu

PRODUCT DATA SHEET

Casco® Remover
February 2023, Version 02.01
02051602000000055

LOCAL RESTRICTIONS

Please note that as a result of specific local regulations the declared data for this product may vary from country to country. Please consult the local Product Data Sheet for the exact product data.

LEGAL NOTES

The information, and, in particular, the recommendations relating to the application and end-use of Casco products, are given in good faith based on Sika's current knowledge and experience of the products when properly stored, handled and applied under normal conditions in accordance with Sika's recommendations. In practice, the differences in materials, substrates and actual site conditions are such that no warranty in respect of merchantability or of fitness for a particular purpose, nor any liability arising out of any legal relationship whatsoever, can be inferred either from this information, or from any written recommendations, or from any other advice offered. The user of the product must test the product's suitability for the intended application and purpose. Sika reserves the right to change the properties of its products. The proprietary rights of third parties must be observed. All orders are accepted subject to our current terms of sale and delivery. Users must always refer to the most recent issue of the local Product Data Sheet for the product concerned, copies of which will be supplied on request or on the website www.casco.eu.

CascoRemover-en-SECASCO-(02-2023)-2-1.pdf